

Installing your Wireless ProTECH Flex Skin Gel Case for the Sonim XP5s

1. To install your Flex Skin Gel Case place your Sonim XP5s Top first, facing upwards into the TPU case



2. Insert the provided easy installation card perpendicular to the surface at a 90° angle. Run it along the length of the phone while pressing down on the bottom left of the phone.





3. Turn the phone to the other side and apply the same process, insert the easy installation card and run it along the side of the TPU case while pressing on the right bottom corner of the phone.



4. Now your Wireless ProTECH Flex Skin Gel Case is installed. The case should be skintight to protect from any damage and add additional grip.



Removal of your Wireless ProTECH Flex Skin Gel Case for the Sonim XP5s

Hold your Sonim XP5s and peel the bottom part of the TPU until the full length of the phone is exposed. Shift the phone to the right side. Peel the Right corner of the TPU case until the bottom of the phone is exposed. Now you can remove your Sonim XP5s out of the Wireless Protech Flex Skin Gel Case.

